


神明地区配置図



5 F	501 2LDK	502 2LDK			集会所				503 2DK	504 3DK
4 F	401 2LDK	402 2LDK		403 1LDK	404 1LDK	405 2DK	406 2DK	407 2DK	408 3DK	
3 F	301 2LDK	302 2LDK		303 1LDK	304 1LDK	305 2DK	306 2DK	307 2DK	308 3DK	
2 F	201 2LDK	202 2LDK		203 1LDK	204 1LDK	205 2DK	206 2DK	207 2DK	208 3DK	
1 F	101 2LDK	102 2LDK		103 1LDK	104 1LDK	105 2DK	106 2DK	107 2DK	108 3DK	

集合住宅断面図

